WILFRID

PERMACON

Concrete Slab




VAN BEEK'S

www.vanbeeks.com

Wilfrid Slab

SPECIFIC DETAILS




INSTALLATION OF SLABS

With its three sizes, the Wilfrid slab can be installed in a linear or modular pattern. It is recommended to use all units of every row to prevent waste when installing the Wilfrid Slab.

- > The unit ratio per layer is 1:1:1
- > The length of units A and B together equals the length of unit C
- > Unit A represents 1/3 and unit B represents 2/3 of the length of unit C

CAUTION! The unit ratio per layer of Wilfrid slab is not the same as the one of Melville 60 slab. The laying patterns for the Wilfrid slab are different.



LAYING PATTERNS

LINEAR LAYING PATTERN

This is only a preview of a linear laying pattern. Replication of this exact pattern may result in a waste of units.

В	Α	С		В	Α	С		
Α	В	С		А	В	С		
С		В	P	A	С	В	Α	
В		С	Α			С	А	
ВА		С	С		А	С		
А	В	С	'	Α	В	С		
	С		A	À	С	В	A	

MODULAR LAYING PATTERN

This is only a preview of a modular laying pattern. Replication of this exact pattern may result in a waste of units.

